

# 台大電機系 光電實驗



授課老師：林晃巖 教授

實驗助教：台大光電所 陳怡霖

E-mail: [r08941118@ntu.edu.tw](mailto:r08941118@ntu.edu.tw)

實驗四. 電光調變器實驗

實驗六. 液晶與偏振實驗

實驗七. 光纖光學實驗

實驗八. 太陽能電池實驗



# Optical Amplifier

## Optical Amplifier :

Semiconductor Optical Amplifier

Raman Amplifier


Erbium-Doped Fiber Amplifier (EDFA).

注意事項

## Experiment:

1. Gain Bandwidth (增益光譜)
2. Gain V.S. Pump Power
3. Gain Saturation
4. Noise Figure


攜帶數位相機紀錄波型和數據



# System setup

(基本配置圖 實驗配置圖)

Tunable lase



Modulator



Electrical Signal In

Optical Signal

Power meter



長程傳輸




EDFA


# The basic principle of light emission

- EDFA (光學放大器) 所使用到的兩種放光機制
- Interaction between light and atoms


## Spontaneous emission




## Stimulated emission



- Optical amplifier : Amplify incident light through **stimulated emission** in most amplifiers.



- EDFA : Use erbium ions ( $\text{Er}^{3+}$ ) fiber.
- Pump Wavelength : 980nm 、 1480nm
- Bandwidth : **1520nm~1570nm**



- Amplified Spontaneous Emission (ASE) :**


The atoms can release their energy spontaneously without concerning with signal photon and it results in energy released with a random phase, polarization and direction. These random photons also become amplified by the same process. **So ASE does not carry signal information. It contributes to noise and degrades the signal.**

# Gain saturation and SNR

- In the small signal regime,

$$P_{out} = P_{in} \times G_{max}$$

As the input signal power increases, the gain will decrease as the EDFA reaches its saturation at a given pump power. This phenomenon is called **EDFA gain saturation**.



- The Signal-to-Noise Ratio (SNR) is defined as

$$SNR = \frac{\text{average signal power}}{\text{noise power}} = \frac{I_p^2}{\sigma^2}$$


$I_p$  is the average current,  $\sigma$  is the root-mean-square (RMS) value of the noise current.

- **Noise Figure(雜訊指數) :**

To quantify the SNR degradation after the signal be amplified. It is the ratio of  $SNR_i$  to  $SNR_o$ .

- NF is commonly expresses in dB as

$$NF_{db} = 10 \bullet \log(NF)$$



- An NF approximation can be expressed as

$$NF = 2n_{sp} \frac{(G-1)}{G} + \frac{1}{G} \quad , \quad n_{sp} = \frac{P_{ASE}}{2h\nu B_o (G-1)}$$

- Here **G is the gain of optical amplifier** (linear unit),  $B_o$  is the optical bandwidth in Hz (the resolution of OSA),  $\nu$  is the frequency,  $h = 6.626 \times 10^{-34} J \cdot s$ ,  $h\nu$  is photon energy,  $P_{ASE}$  is the amplified spontaneous emission noise power.
- $n_{sp}$  is a constant called the spontaneous emission factor

# 實驗器材

- Tunable Laser (可調變雷射光源)






# 實驗器材

- EDFA (光學放大器)

指示燈

EDFA 電流強度旋鈕



電源總開關


光纖 輸入 輸出端

# 實驗器材

- OSA (光譜分析儀)

訊號顯示螢幕

光訊號輸入位置




訊號調整控制板

電源總開關+指示燈


# 1. Gain Bandwidth

- Figure (a), to measure **spontaneous amplified emission (ASE)**, when the signal is not fed into EDFA. Connect EDFA output to OSA(Optical Spectrum Analyzer) through attenuator. In this setup, **no signal** is coupled into the fiber and only pump is. The output spectrum is ASE.




## 2. Gain V.S. Pump Power

- Figure (b), Use the **variable optical attenuator** to set the fixed **input** power into the **EDFA**. To measure the signal gain versus the pump current, increase the **EDFA pump current** from **200mA to 400mA** in 100mA increments while **measuring** optical **output** power.



## 3. Gain Saturation

- Figure (c), **Measure** and record the EDFA **output** power for the input power levels from **-30dBm to -5dBm**, in step of 5dB, at different EDFA pump currents : **250**. Plot the **gain v.s. the input** power and locate the input power with 3dB gain suppression. Compare the 3dB gain suppression input powers and the saturation output power level at the different pump current.



# 預報問題

- 說明EDFA架構與工作原理
- Optical Spectrum analyzer (OSA) 架構 應用 及工作原理

注意事項

攜帶數位相機紀錄波型和數據

